

Load warning indicator

Examine 1 indicator

Examine 2 indicator

ENTER button

Arrow buttons
UP
DOWN
LEFT
RIGHT


LCD Display

Line warning indicator

OK indicator

CLEAR button

Power Indicator



CLEAR

ENTER

POWER

Artesis